

QUIK-FELT

MSA

QUIK-FELT

Quik-felt Synthetic Underlayment Installation Instructions:

- Quik-Felt must be installed on code approved roof decks, which are properly ventilated according to all applicable building codes.
- The roof deck must be clean, solid, properly fastened and free of voids and or damage
- Repair all damage to deck before proceeding. For seams, joint or tears, repairs may be made using flashing tape or equivalent.
- Quick-Felt must be installed printed side up.
- Plastic cap fasteners must be used to secure Quick-Felt properly.
- The plastic cap fasteners should be a minimum of 1' length and have caps of min. .1" in diameter.
- The plastic cap fastener spacing should be at 12" oc. horizontally along the indicated fastener placement lines at the top and bottom and at 24" oc. in the center lines printed on the sheet
- Top and bottom overlaps should be 4" minimum as indicated by the lay-up/fastener lines printed on the sheet.
- Place the fasteners 2" in from the edges of the top and bottom laps.
- End overlaps should be 12" minimum and fastened to 12" oc. vertically along the overlaps at 2" in from the end of the top player.
- The plastic caps fasteners should be driven tight to the surface of the Quick-felt without cutting into sheet.
- Quick-felt should be extended at least 12" past all hips and valleys
- Quick-felt installed on less than 4:12 slopes should be applied in a double coverage method {Overlapping by the normal 4"} Fastening can be through both layers.
- Asphalt adhesives may also be used to seal joints, flashings and laps.

CAUTIONS


Always learn and observe safe roofing practices according to OSHA and local building code requirements. Always use caution when walking on sloped roof decks and Quik-Felt underlayments. Do not walk on unsecured Quik-Felt or any other loose roofing material lying on sloped roof decks. Dust, dew, water, or debris creates unsafe conditions on the roof. The presence of any foreign matter may drastically change the coefficient of friction (traction) on Quik-Felt or any other material on a sloped roof deck. Failure to always use proper safety equipment and footwear can result in serious injury or even death. **Underlayment is NOT roofing. When inclement weather is forecasted, tarps should be used.**

SAFETY FIRST

COMPLIANCES / CODE APPROVALS

- Certain Performance characteristics meet or exceed - ASTM D226, ASTM D4869
- ASTM D 108, Fire Resistance (Class A Rating)
- Code Compliance Research Report CCRR-1057
- FL Building Code (FL 17188)
- Meets requirements of ICC AC-188
- UV Resistant upto 60 Days.
- ICC ES AC48 Approved

Follow the ARMA (Asphalt Roof Manufacturing Assn.) recommendations for installing shingle underlayments and flashings for best roofing practices



Technical Data			
	Coverage w/4" Lap	Roll Size	Material Per Roll
Quik-Felt	917 sq. ft.	48" x 250"	1000 sq. ft.

MSA

CALL: 800-489-2391

MID-STATES ASPHALT

1637 51ST AVENUE • TUSCALOOSA, AL 35401

WWW.MSAROOF.COM